

Powroll XR75 #18205



Installation Instructions

Your Powroll exhaust will install differently than a stock system. By following our basic instructions listed below, and referring to the photo, you should have no problems.

Carefully wash bike before removing old exhaust system. Be especially concerned with the areas around the stock pipe. Remove stock exhaust.

Assemble the Powroll exhaust system & place it on the machine (use a new OEM exhaust pipe flange gasket). Note mounting locations on the new pipe, and check your mounting hardware kit. Be sure you have the correct bracket and bolts to mount the Powroll pipe.

Install springs and mounting hardware, finger tighten all bolts. Head pipe until everything comes into alignment. Check to be sure the exhaust system clears all body work, hoses, wires and cables.

Follow tuning instructions included with this kit.



Powroll Inc • PO Box 920 • Redmond OR 97756
Phone 541-923-1290 • Fax 541-923-5637 • Email mail@powroll.com

www.powroll.com