

POWROLL TECH

REQUIRED PROCEDURE

CRF150 & 230 HEADPIPE INSTALLATION

Remove the stock headpipe.

You will need to remove the bushing located in the stock muffler prior to installing the new Powroll oversized headpipe.

A spring puller or needle-nose pliers work well for this.

Loosen all mounting bolts on the muffler, be sure headpipe mounting clamp is completely loose.

Install the Powroll headpipe by slipping it into the head and muffler simultaneously. Slide into place by gently wiggling pipe until the flange seats against the head.

If you have problems getting the pipe to fit, be certain that ALL muffler mounting bolts are loose, and that the muffler can move freely, otherwise the pipe will not align properly.

