

# ***Powroll***

---

## **Vented Valve Cap**

---



---

**For Honda 50's, 70's, TRX 90  
& TRX 250EX**

---

## ***Powroll Vented Valve Cap Installation Instructions***

- 1 Allow Engine to completely cool before installing your new Vented Valve Cap. Do not install while engine is hot!
- 2 **HONDA 50-70 & 90's**—Remove stock Intake (top) valve cap. Do not install Vented cap on Exhaust (lower) valve cap. This will cause oil loss and possible engine damage!
- 2 **HONDA TRX 250EX**—Remove stock exhaust (front) valve cap.
- 1 Remove O-Ring from stock Valve Cap and install it on your Powroll Vented Valve Cap
- 2 Lubricate the threads of the Powroll Vented Cap. You can use AntiSeize or your regular motor oil. Do not install cap dry!

- 3 Install your vented cap and tighten to OEM specifications. Do not over-tighten.
- 4 Route vent hose up towards fuel tank, directing the end of the hose downward (to prevent water and debris from getting in!).
- 5 In extremely dusty conditions, Powroll recommends the use of a filter on the end of the vent tube. You can use K&N filter #62-1000 or any other filter designed for crankcase breathers.

Questions? Comments?  
Contact us!

***Powroll Inc***

PO Box 920, Redmond OR 97756

Phone: (541) 923-1290

Fax: (541) 923-5637

Email: [mail@powroll.com](mailto:mail@powroll.com)

***[www.powroll.com](http://www.powroll.com)***